Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Infiniti	M45	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	M45	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	Q45	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX4	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX4	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX4	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX4	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX4	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX56	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Infiniti	QX56	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2003	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2004	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2005	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	Axiom	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Isuzu	Axiom	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Isuzu	Hombre	1998	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	Hombre	1999	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	Hombre	2000	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Isuzu	i-280	2006	Immobilizer Bypass	Passlock	556LW				
Isuzu	i-350	2006	Immobilizer Bypass	Passlock	556LW				
Isuzu	Rodeo	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Isuzu	Rodeo	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Isuzu	Rodeo Sport	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	S-type	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	S-type	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	S-type	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	S-type	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	S-type	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ Series	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XJR	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK Series	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XK8	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XKR	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XKR	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XKR	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	XKR	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	X-type	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	X-type	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jaguar	X-type	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Jeep	Cherokee	1999	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Cherokee	2000	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Cherokee	2001	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Commander	2006	Immobilizer Bypass	Sentry Key	556CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Commander	2006	Door Lock Interface	Multiplex	456LW				
Jeep	Grand Cherokee	1996	Door Lock Interface	Data Bus	455TW				
Jeep	Grand Cherokee	1997	Door Lock Interface	Data Bus	455TW				
Jeep	Grand Cherokee	1998	Door Lock Interface	Data Bus	455TW				
Jeep	Grand Cherokee	1999	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	1999	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2000	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2000	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2001	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2001	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2002	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2002	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2003	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2003	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2004	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2004	Door Lock Interface	Data Bus	457CW				
Jeep	Grand Cherokee	2005	Immobilizer Bypass	Sentry Key	556CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2005	Door Lock Interface	Multiplex	456LW				
Jeep	Liberty	2002	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2002	Door Lock Interface	Data Bus	457CW	456LW			
Jeep	Liberty	2003	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2003	Door Lock Interface	Data Bus	457CW	456LW			
Jeep	Liberty	2004	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2004	Door Lock Interface	Data Bus	457CW	456LW			
Jeep	Liberty	2005	Immobilizer Bypass	Sentry Key	556CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2005	Door Lock Interface	Multiplex	456LW				
Jeep	Wrangler	1998	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	1999	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2000	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2001	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2002	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Jeep	Wrangler	2003	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2004	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2005	Immobilizer Bypass	Sentry Key	555CW		556UW	DesignTech 20402	DesignTech 29402
Kia	Amanti	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Kia	Amanti	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Kia	Optima	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Kia	Spectra (2.0L)	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Kia	Spectra (2.0L)	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Kia	Sportage	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	LR3	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2003	Immobilizer Bypass	EWS III	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2004	Immobilizer Bypass	EWS III	556UW			DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2005	Immobilizer Bypass	EWS III	556UW			DesignTech 20402	DesignTech 29402
Lexus	ES 300	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2003	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 330	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	ES 330	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	ES 330	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	GS 300	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2003	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2004	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2005	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2006	Immobilizer Bypass	Transponder	N/A				
Lexus	GS 400	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 400	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 400	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2003	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2004	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2005	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2006	Immobilizer Bypass	Transponder	N/A				
Lexus	GX 470	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	GX 470	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	GX 470	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	GX 470	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	IS 250	2006	Immobilizer Bypass	Transponder	N/A				
Lexus	IS 300	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2003	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2004	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2005	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 350	2006	Immobilizer Bypass	Transponder	N/A				
Lexus	LS 400	1997	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 400	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 400	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 400	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 430	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 430	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 430	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 430	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LS 430	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LX 470	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LX 470	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LX 470	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	LX 470	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	RX 300	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2001	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2002	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2003	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 330	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	RX 330	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	RX 330	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	RX 400h	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	SC 300	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 300	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 300	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 400	1998	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Lexus	SC 400	1999	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 400	2000	Immobilizer Bypass	Transponder	555XW		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	SC 430	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	SC 430	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	SC 430	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lexus	SC 430	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Blackwood	2002	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2001	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2002	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2000	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2001	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2002	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2003	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2004	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2005	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2006	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Mark LT	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Mark VIII	1997	Immobilizer Bypass	SecuriLock	556UW			DesignTech 20402	DesignTech 29402
Lincoln	Mark VIII	1998	Immobilizer Bypass	SecuriLock	556UW			DesignTech 20402	DesignTech 29402
Lincoln	Navigator	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2001	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2002	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2001	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2002	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Zephyr	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	3	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	3	2004	Door Lock Interface	Multiplex	456LW				
Mazda	3	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	3	2005	Door Lock Interface	Multiplex	456LW				
Mazda	6	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	6	2003	Door Lock Interface	Multiplex	456LW				
Mazda	6	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	6	2004	Door Lock Interface	Multiplex	456LW				
Mazda	6	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	6	2005	Door Lock Interface	Multiplex	456LW				
Mazda	626	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	626	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	626	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	626	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	626	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	B 2500, B 3000, B 4000	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B 2500, B 3000, B 4000	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2001	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2002	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Miata	2001	Door Lock Interface	Multiplex	456LW				
Mazda	Miata	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Miata	2002	Door Lock Interface	Multiplex	456LW				
Mazda	Miata	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Miata	2003	Door Lock Interface	Multiplex	456LW				
Mazda	Miata	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Miata	2004	Door Lock Interface	Multiplex	456LW				
Mazda	Miata	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Miata	2005	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1994	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1995	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1996	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1997	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Millenia	1998	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Millenia	1999	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Millenia	2000	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Millenia	2001	Door Lock Interface	Multiplex	456LW				
Mazda	Millenia	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	Millenia	2002	Door Lock Interface	Multiplex	456LW				
Mazda	MPV	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2000	Door Lock Interface	Multiplex	456LW				
Mazda	MPV	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2001	Door Lock Interface	Multiplex	456LW				
Mazda	MPV	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2002	Door Lock Interface	Multiplex	456LW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Mazda	MPV	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2003	Door Lock Interface	Multiplex	456LW				
Mazda	MPV	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2004	Door Lock Interface	Multiplex	456LW				
Mazda	MPV	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	MPV	2005	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	1997	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	1998	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	1999	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	2000	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	2001	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	2002	Door Lock Interface	Multiplex	456LW				
Mazda	Protege	2003	Door Lock Interface	Multiplex	456LW				
Mazda	Protege5	2002	Door Lock Interface	Multiplex	456LW				
Mazda	Protege5	2003	Door Lock Interface	Multiplex	456LW				
Mazda	RX-8	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	RX-8	2004	Door Lock Interface	Multiplex	456LW				
Mazda	RX-8	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mazda	RX-8	2005	Door Lock Interface	Multiplex	456LW				
Mazda	Tribute	2001	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2001	Door Lock Interface	Multiplex	456LW				
Mazda	Tribute	2002	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2002	Door Lock Interface	Multiplex	456LW				
Mazda	Tribute	2003	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2003	Door Lock Interface	Multiplex	456LW				
Mazda	Tribute	2004	Immobilizer Bypass	SecuriLock	555SW		556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2004	Door Lock Interface	Multiplex	456LW				
Mazda	Tribute	2005	Immobilizer Bypass	SecuriLock	556UW			DesignTech 20402	DesignTech 29402
Mazda	Tribute	2005	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	C 230	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C 230	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C 230	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	C Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CL Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CL Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2001	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	CLK Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2002	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	E Class	1997	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 430	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 430	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	ML Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S 320	1997	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S 420	1997	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S 500	1997	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2000	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	S Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2001	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	S Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2002	Door Lock Interface	Multiplex	456LW				
Mercedes Benz	SL Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SL Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	1998	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mercury	Cougar	1997	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	1999	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2000	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2001	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2002	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2001	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2002	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Marauder	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Marauder	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mariner	2005	Immobilizer Bypass	SecuriLock	556UW			DesignTech 20402	DesignTech 29402
Mercury	Mariner	2005	Door Lock Interface	Multiplex	456LW				
Mercury	Mariner	2006	Immobilizer Bypass	SecuriLock	556UW			DesignTech 20402	DesignTech 29402
Mercury	Mariner	2006	Door Lock Interface	Multiplex	456LW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Mercury	Milan	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Montego	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Montego	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1997	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2000	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2001	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2002	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2006	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	1999	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	2000	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1996	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1997	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1998	Immobilizer Bypass	PATS	555FW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1999	Immobilizer Bypass	PATS	555PW	555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2000	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2001	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2002	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2003	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2004	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2005	Immobilizer Bypass	SecuriLock	556SW		556UW	DesignTech 20402	DesignTech 29402
Mini	Cooper	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mini	Cooper	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mini	Cooper	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2006	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Endeavor	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Endeavor	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Outlander	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Mitsubishi	Outlander	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	350Z	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	350Z	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	350Z	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Altima	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Armada	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Frontier	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Maxima	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Murano	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Murano	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Murano	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	1999	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Pathfinder Armada	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Quest	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4
Nissan	Quest	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2000	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2001	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2002	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2003	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Sentra	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Titan	2004	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Titan	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Nissan	Xterra	2005	Immobilizer Bypass	Transponder	556UW			DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1996	Immobilizer Bypass	Passlock I	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1997	Immobilizer Bypass	Passlock I	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1998	Immobilizer Bypass	Passlock I	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	1999	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	1999	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Alero	2000	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2000	Combo Interface	Data Bus	457GW				
Oldsmobile	Alero	2000	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Alero	2001	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2001	Combo Interface	Data Bus	457GW				
Oldsmobile	Alero	2001	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Alero	2002	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2002	Combo Interface	Data Bus	457GW				
Oldsmobile	Alero	2002	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Alero	2003	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2003	Combo Interface	Data Bus	457GW				
Oldsmobile	Alero	2003	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Alero	2004	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2004	Combo Interface	Data Bus	457GW				
Oldsmobile	Alero	2004	Door Lock Interface	Multiplex	456LW				
Oldsmobile	Aurora	1995	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1996	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1997	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1998	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1999	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2001	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2001	Combo Interface	Data Bus	457GW				
Oldsmobile	Aurora	2002	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2002	Combo Interface	Data Bus	457GW				
Oldsmobile	Aurora	2003	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2003	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	1998	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	1999	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	1999	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	2000	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2000	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	2001	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2001	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	2002	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2002	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	2003	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2003	Combo Interface	Data Bus	457GW				
Oldsmobile	Bravada	2004	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2004	Combo Interface	Data Bus	457GW				
Oldsmobile	Cutlass	1997	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass	1998	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass	1999	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Ciera	1995	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Ciera	1996	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1995	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1996	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1997	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1995	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1996	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1997	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight LSS	1998	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight LSS	1999	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1998	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1998	Combo Interface	Data Bus	457GW				
Oldsmobile	Intrigue	1999	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1999	Combo Interface	Data Bus	457GW				
Oldsmobile	Intrigue	2000	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2000	Combo Interface	Data Bus	457GW				
Oldsmobile	Intrigue	2001	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2001	Combo Interface	Data Bus	457GW				
Oldsmobile	Intrigue	2002	Immobilizer Bypass	Passlock II	556LW	555LW		DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2002	Combo Interface	Data Bus	457GW				
Oldsmobile	Ninety-Eight	1992	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1993	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1994	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1995	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1996	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1997	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1998	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Regency	1997	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Regency	1998	Immobilizer Bypass	VATS	652T resistor pack			DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	1999	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2000	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2000	Combo Interface	Data Bus	457GW				
Oldsmobile	Silhouette	2001	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2001	Combo Interface	Data Bus	457GW				
Oldsmobile	Silhouette	2002	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2002	Combo Interface	Data Bus	457GW				
Oldsmobile	Silhouette	2003	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2003	Combo Interface	Data Bus	457GW				
Oldsmobile	Silhouette	2004	Immobilizer Bypass	PASS-Key III	555GW		556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2004	Combo Interface	Data Bus	457GW				